RadioShack

User's Guide **63-245**

Big-Digit Alarm Clock

*Thank you for purchasing your Big-Digit Alarm Clock from **RadioShack**. Please read this user's guide before installing, setting up, and using your new clock.*

Check package contents

Alarm Clock

Features

- Large backlit display
- Snooze feature

① Install Batteries

Open the battery cover on the bottom of the clock and insert 2 AA batteries (not supplied) into the battery compartment, following the polarity symbols (+ and –) marked inside. Then replace the cover.

Battery Notes

- Dispose of batteries promptly and properly. Do not burn or bury them.
- Use only fresh batteries of the required size and type.
- Do not mix old and new batteries, different types of batteries (alkaline, or rechargeable), or rechargeable batteries of different capacities.
- If you do not plan to use your clock for more than a month, remove the battery. Batteries can leak chemicals that can damage electronic parts.

12HR/24HR
Slide to select 12 or 24 hour display.

SNOOZE/ALARM ON/ ALARM OFF
- Slide to the **SNOOZE** position to activate the snooze function.
- Slide to the **ALARM ON/ ALARM OFF** position to activate/deactivate the alarm.

MIN
Set the minute.

HR
Set the hour.

LOCK/CLOCK SET/ALARM SET
- Slide to the **CLOCK SET** or **ALARM SET** position to set the clock and alarm time.
- Slide to the **LOCK** position to confirm the clock and alarm time.

LIGHT/ALARM STOP
- Press once for a 5 second backlight.
- When the alarm sounds, press to stop the alarm.

② Set the Clock

1. Slide **LOCK/CLOCK SET/ALARM SET** to **CLOCK SET**. The hour and minute digits flash.
2. Slide **12HR/24HR** on the back of the clock to select 12 or 24 hour time format.
3. Press **HR** to set the hour and **MIN** to set the minute.
4. Slide **LOCK/CLOCK SET/ALARM SET** to the **LOCK** position to confirm clock time.

***Note**: PM only appears in the 12-hour clock format.*

③ Set the Alarm

1. Slide **LOCK/CLOCK SET/ALARM SET** to **ALARM SET**. "AL" appears and the hour and minute digits flash.
2. Slide **12HR/24HR** switch on the back of the clock to select 12 or 24 hour time format.
3. Press **HR** to set the hour and **MIN** to set the minute.
4. Slide **LOCK/CLOCK SET/ALARM SET** to **LOCK** to confirm the alarm time.
5. Slide **SNOOZE/ALARM ON/ALARM OFF** to **ALARM ON** to activate the alarm and slide to **ALARM OFF** to deactivate the alarm.

***Note**: When the alarm sounds in **ALARM ON** mode, press **LIGHT/ALARM STOP** to turn the alarm completely off for 24 hours.*

④ Snooze Function

Slide **SNOOZE/ALARM ON/ALARM OFF** to **SNOOZE**. ¼ and appear on the display. When the alarm sounds, press **LIGHT/ALARM STOP** to stop for 8 minutes. Press it when the alarm goes off again to delay alarm for 8 more minutes.

Care and Use

- Keep your alarm clock dry; if it gets wet, wipe it dry immediately. Keep your alarm clock away from dust and dirt. Handle your alarm clock carefully; do not drop it.
- Avoid contact with any corrosive materials such as perfume, alcohol, or cleaning agents.
- Do not subject the alarm clock to excessive force, shock, dust, temperature or humidity. Any of these conditions may shorten the life of the alarm clock.
- Do not tamper with any of the internal components of this alarm clock. This will invalidate the warranty and may cause damage.

Limited Warranty

RadioShack warrants this product against defects in materials and workmanship under normal use by the original purchaser for **ninety (90) days** after the date of purchase from a ***RadioShack***-owned store or an authorized ***RadioShack*** franchisee or dealer. ***RADIOSHACK*** MAKES NO OTHER EXPRESS WARRANTIES.

This warranty does not cover: (a) damage or failure caused by or attributable to abuse, misuse, failure to follow instructions, improper installation or maintenance, alteration, accident, Acts of God (such as floods or lightning), or excess voltage or current; (b) improper or incorrectly performed repairs by persons who are not a ***RadioShack*** Authorized Service Facility; (c) consumables such as fuses or batteries; (d) ordinary wear and tear or cosmetic damage; (e) transportation, shipping or insurance costs; (f) costs of product removal, installation, set-up service, adjustment or reinstallation; and (g) claims by persons other than the original purchaser.

Should a problem occur that is covered by this warranty, take the product and the ***RadioShack*** sales receipt as proof of purchase date to any ***RadioShack*** store in the U.S. ***RadioShack*** will, at its option, unless otherwise provided by law: (a) repair the product without charge for parts and labor; (b) replace the product with the same or a comparable product; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of ***RadioShack***. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

RADIOSHACK EXPRESSLY DISCLAIMS ALL WARRANTIES AND CONDITIONS NOT STATED IN THIS LIMITED WARRANTY. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY AND, IF APPLICABLE, THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, SHALL EXPIRE ON THE EXPIRATION OF THE STATED WARRANTY PERIOD.

EXCEPT AS DESCRIBED ABOVE, ***RADIOSHACK*** SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO THE PURCHASER OF THE PRODUCT OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE AND ANY LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT AND ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF ***RADIOSHACK*** HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some States do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from State to State. You may contact ***RadioShack*** at:

RadioShack Customer Relations
300 RadioShack Circle, Fort Worth, TX 76102 04/08

www.RadioShack.com

Protect the environment. Go to E-CyclingCentral.com to find an electronic recycling center near you.

©2009. ***RadioShack*** Corporation.
All rights reserved. ***RadioShack*** and ***RadioShack.com*** are trademarks used by ***RadioShack*** Corporation.

Printed in China 02A09 63-245